




40358



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.








1x



2x

1



4



1x


2





1x

3



1x




1x

4



5



1




2



3



4





1x




1x

1



2





1x

1



2






1x





1x

1






2




3







4




12

5





1






1x




1x

2






3






4





2x

5




2x





1x

6






7




8





1x

9




20



4x

10






2x




2x

11





2x






12



13






1x



1x

14





1x

15



2x



2x




2x



2x

16






17

1



2



3





4






18






19


1



2




3



4



5








2x



1x

20




30



4x

21






2x




2x

22





2x





23






1x




1x


24




34




25





26






1x



1x

27






3x



3x

28







3x



3x


29






30


1




2




3




4



5








1x



1x

31





1x




1x



1x


32






1x

33



34




1x
459901


3x
4504369


1x
6054551


1x
9327


1x
6051511


3x
6034044


2x
6070698


2x
4556152


1x
368001


1x
6025192


2x
6023806


2x
4515347


1x
6139649


2x
6139650


2x
6151221


2x
6092587


2x
614121



3x
4504379


3x
389921


1x
383321


3x
6029946


2x
4633914


3x
383221


1x
4578503


1x
6116616


1x
6153321


1x
6153328


1x
4114584


1x
389924


1x
6214544


1x
6112219


1x
6223854


1x
6219611


10x
6168646


1x
459926


1x
302426


1x
4517925


1x
6106280


3x
302326


3x
4225201


4x
6093525


1x
302226


2x
302126


1x
4297713


1x
4567908


1x
4295260


1x
6171069


1x
4614107



1x
6240030



1x
4120158



1x
6210400



2x
6133854



1x
4211103



1x
6096091



1x
6022032



2x
4622574



2x
6100644



2x
6055380



2x
4211222



1x
4222693



1x
4198316



1x
6146701



2x
6253231



2x
4626904



2x
4211183



1x
4211235



2x
4211476



1x
6065515



1x
6210729



1x
6150320



2x
6015424



1x
4506003



3x
4211181



1x
4540203



2x
6055384



1x
4620433



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



1x
6076806



7x
6117405



1x
4211462



2x
4211398



1x
6055383



1x
4228198



2x
4619636



1x
4225715